



In our own lab tests, we use a torch to place an extremely hot flame with strong pressure against the Firefighter product and 100% acrylic flat house paint. The products were applied on a wood siding board and allowed to cure for 2 days before tested. A torch best represents the heat of a typical wild fire and the gusts of wind that are created in a wild fire. Notice that the Firefighter creates a protective, non-burning char to keep the flame from reaching the substrate.